



Mercedes-Benz

SDS/DAS Walk Through Guide

Please use this guide, in conjunction with the module 2.8, to help you navigate through the SDS/DAS screens. Please see instructor if you have any problems.

Step 1. Connect SDS/DAS – please have your instructor insure a positive connection of the test equipment to the vehicle and that all cables are clear from potential damage.

Step 2. On the desktop of the SDS laptop, double click the “DAS” icon to start the program. (When running, you should see a spinning Mercedes-Benz star.)

Notes: The buttons on the bottom of the screen function as follows:

ESC – ends the DAS program or returns to initial screen

F1 – moves you backwards to the previous page if you make a mistake

F2 – moves you forward in the program

F3 – enters data or selects highlighted item

On keyboard: Arrows – scrolls the highlighted selection up / down

Selecting a vehicle: Press F2 - read notes - Press F2 – Press F3 to select “CARS” – using the arrow keys, scroll down to the “230” and press F3. Press F3 to select “Left-hand steering”. Press F3 to select “230.475 SL500”. PLEASE WAIT.....

Accessing AAC: Using the arrows, scroll down and highlight “Control Units” and press F3. Scroll to “Air Conditioning” and press F3. Select “AAC – Automatic air conditioning” and press F3. Next, press F4 to answer “NO” to the question. Now return to the module to complete this section. When you are done with AAC section, press F1 three times to return to “Control unit groups”.

Accessing Seat Control Modules: Scroll to “Seats and doors” and press F3. For the left seat, select “ESA-FL” ; if you’re doing the right seat, select “ESA-FR”. Next, press F4 to answer “NO” to the question. Return to the module and follow the prompts. When you are done with both seats, press F1 three times to return to “Control unit groups”.

Quick Testing (Short test) to clear fault codes: If you are in the “Control unit groups” screen, press F1 once to move backwards to “Main groups”. Scroll to “Short test” and press F3. Then wait for test to complete. Next, press F9 to clear all codes and follow screen prompts. Then press F1 to back out.

